



Veratox for Casein Allergen Procedure

Note: Please read kit instructions completely before performing test.


Questions? Call 800/234-5333 or 517/372-9200.



1. Add 150 µL controls and extracted samples to transfer wells.




2. Transfer 100 µL to the antibody wells. Incubate for 10 minutes.




3. Dump liquid from antibody wells.



4. Wash wells thoroughly 5 times with washing buffer solution.




5. Tap out water on absorbent paper towel.




6. Transfer 100 µL conjugate from reagent boat to antibody wells using 12-channel pipettor. Incubate for 10 minutes.




7. Repeat steps 3-5 by dumping out the liquid, thoroughly washing the wells and tapping dry.



8. Transfer 100 µL substrate from reagent boat to antibody wells using 12-channel pipettor. Incubate for 10 minutes.



9. Transfer 100 µL Red Stop from reagent boat to antibody wells.



10. Read results in a microwell reader with a 650 nm filter.

Product Specifications

Range of quantitation:

2.5 - 15 ppm

Controls provided:

0, 2.5, 5, 10 and 15 ppm

Testing time:

Less than 1 hour



620 Lesher Place • Lansing, MI 48912
800/234-5333 (USA and Canada only) • 517/372-9200 • fax: 517/372-2006
e-mail: foodsafety@neogen.com • www.neogen.com